




Illuminated Magnifier


Top View




Front View



Magnifier Head Bulb




Bulb Holder



Switch

Torch Body



Bulb Replacement

Pull to remove Magnifier Head from splined Bulb Holder.

Unscrew bulb (2.2v - 0.25A)

Replace correct bulb and push Magnifier Head back onto spline of bulb holder with switch and magnifier lens aligned.

Battery Replacement

Remove Magnifier Head from splined Bulb Holder.

Grip splined diameter and unscrew torch body.

Insert 2 x Size L - 1.5v batteries with + ends pointing towards bulb.

Replace bulb holder and Magnifier Head as above.